

Wiring for Basic TV & HDTV

Basic TV is where you have local equipment such as Video Game system, DVD player, Digital Cable Box, VCR, Media player, Home Entertainment system, Home Audio Amplifier, etc... located at the TV.






Instructions: Mount TV outlet right beside an electrical outlet, at the same height. Typical Basic TV outlet height is 16” to the centre of the wall plate.

For full instructions go to: www.stemic.ca/WiringYourHome.htm and buy the booklet “How to Wire for the Future”.

Tools Required: Drill, Measuring Tape, Wire cutters

Materials required:

- 1 x [TV wire](#) 
- 1 x [Internet wire](#) 
- 1 x [Standard single-gang low-voltage electrical box \("mud-ring"\)](#) 
- 1 x Vapour bag (if needed)
- Plastic Electrical staples
- Electrical tape



For full instructions go to: www.stemic.ca/WiringYourHome.htm and buy the booklet "How to Wire for the Future".

Installation of wall plate for Basic TV & HDTV

Tools Required:

- Screw driver or Drill

- [Internet \(RJ45\) crimp tool](#)



- [TV \(F\) crimp compression tool](#)



- [Wire strippers](#)



or TV (F) stripping tool



- [110-Punch down tool](#)



Materials required:

[TV \(F\) connector for wall-plate](#)



- [TV \(F\) connectors](#)



- [Internet \(RJ45\) plug for Wall plate](#)



- Wall plate



For full instructions go to: www.stemic.ca/WiringYourHome.htm and buy the booklet “How to Wire for the Future”.

Thanks!

Stephen McKenzie